# Shinephone APP battery control instruction

1. Find TOU-charge option

**Login shinephone--my device list--choose the inverter--control
Notice:pass word is growatt+year+month+day e.g. growatt20220210**

2. Setting

Just need put the time period and enable the slots after press done,the setting will work everyday.some old firmware will feedback error,please contact Growatt engineer to upgrade firmware.